


Quick guide - CAP Controller



1 Download the application (app) 'AKVA CAP configurator' from Google Play

2 When the controller is connected to the CAP, connect the USB controller to the mobile phone:



3 It is now possible to read and configure the Camera-ID and the Video channel.



Short vibration identifies reading possibility

Longer vibration identifies writing possibility



Correct video channel can only be read when camera is activated in the AKVAconnect software. Writing is possible at any time.